


FlareAssist+ Radar Version 4.1 Splitter Cable

Plug Backside

The following connections are for those that do not wish to use the Splitter Cable / Audio Cable and want to hardwire the FlareAssist+ Radar (Gear Announce) unit into the aircraft.



Reversal of the Power (Red) and Ground (Black) will cause internal damage to the circuitry and is not covered under warranty!

Recreational Mobility
Valkaria Airport (X59)
1 Pilots PI
Malabar, FL 32950

(321) 253-9434

jim@recreationalmobility.com

www.flareassistradar.com